Suggested Activities

The Coin-u-lator can be used as a simple coin-counting calculator. Using real coins or realistic play coins, try the following:

1. Count pennies from 1¢ to 25¢.
2. Count nickels from 5¢ to $1.00.
3. Count dimes from 10¢ to $1.00.
4. Count quarters from 25¢ to $1.00.
5. Count mixed coins up to $1.00
6. Count the coins in your pocket.
7. Count the coins in your wallet.
8. Count the coins in your piggy bank.
9. Ask to count the coins in Dad's pocket.
10. Ask to count the coins in Mom's purse.

Developed for PCI Educational Publishing by Dennis P. McElhone and designed by Larry Felder in cooperation with AZtech Inc, NIDRR, U.S. Department of Education and ParentBanc. U.S. Patent Number: 5,347,473

© 1998, PCI Educational Publishing. All rights reserved.

PCI Educational Publishing
2800 NE Loop 410, #105
San Antonio, TX 78218

ParentBanc
44 East Ave, #100
Austin, TX 78701
1-800-471-3000

POWER SOURCE
3 – AA batteries
(INCLUDED)
Remove protective strip from batteries on back of unit before use.

Made in China.

PCI 700

PCI

COIN-U-LATOR℠

Instruction Guide
and Suggested Activities

IMPORTANT!
Remove protective strip from batteries on back of unit before use.

Operating Instructions

To activate the Coin-u-lator, press the **ON** button. The LCD screen will show either a dollar sign and decimal point or the words Dollars and Cents, depending on which mode it is in. You can change the mode by pressing the Dual Display button indicated by the **$** sign.To reset the Coin-u-lator press the **ON** button.

Press the **OFF** button when you are through using the Coin-u-lator. If you forget to turn the Coin-u-lator off, it will turn itself off after 10 minutes.

When a **COIN** or **DOLLAR** button is pressed, the Coin-u-lator shows that amount on the screen. Each additional button pressed adds to that amount. A sliding switch at the bottom of the unit allows you to change from **Plus** to **Minus** mode and back, as indicated by a symbol at the top left corner of the screen. A **Mute** button, found next to the **OFF** button, turns the sound off and on as indicated by a symbol at the bottom left corner of the LCD. The **OOPS** button clears the last entry if an error is made.

Game Instructions

Press the **GAME** button to activate the two fun games. This button is used to change from one game to another or to return to the coin-counting mode. The **Matching Game** give a random dollar amount and the player matches that amount by pressing a combination of money buttons. On the **Coin-Count** game, the player must choose the right combination of coins to match an amount. Coin symbols on the bottom of the LCD show the number of each coin selected.